

REMOVAL

1. REMOVE STEERING WHEEL PAD ([See page SR-13](#))
2. REMOVE STEERING WHEEL ([See page SR-13](#))
3. REMOVE UPPER AND LOWER COLUMN COVERS ([See page SR-13](#))
4. REMOVE SPIRAL CABLE ([See page SR-13](#))