


INSTALLATION

1. INSTALL AXLE HUB WITH DISC TO SPINDLE

- Place the axle hub with disc to the spindle.
- Install the outer bearing.
- Install the thrust washer.




2. ADJUST PRELOAD

- Using SST, torque the adjusting nut.
SST 09607-60020
Torque: 59 N·m (600 kgf·cm, 43 ft·lbf)
- Turn the hub right and left 2 or 3 times.
- Loosen the nut until it can be turned by hand.
- Using SST, torque the adjusting nut again.
SST 09607-60020

Torque: 5.4 N·m (55 kgf·cm, 48 ft·lbf)

NOTICE:

Check that the bearing has no play.




- Using a spring tension gauge, measure the preload.

Preload (at starting):

26 – 52 N (2.7 – 5.3 kgf, 6.0 – 11.7 lbf)

3. INSTALL LOCK WASHER AND LOCK NUT

- Install a new lock washer and lock nut.




- Using SST, torque the lock nut.

SST 09607-60020

Torque: 64 N·m (650 kgf·cm, 47 ft·lbf)

- Check that axle hub turns smoothly and that the bearing has no play.



- (d) Using a spring tension gauge, check the preload.

Preload (at starting):

26 – 52 N (2.7 – 5.3 kgf, 6.0 – 11.7 lbf)

If it is not within the specification, adjust it with the adjusting nut after removing the lock washer and lock nut.

- (e) Secure the lock nut by bending one of the lock washer teeth inward and the other lock washer teeth outward.

4. w/ Free Wheel Hub:


INSTALL FREE WHEEL HUB (See page SA-30)

5. w/o Free Wheel Hub:

INSTALL FLANGE

- (a) Place a new gasket in position on the axle hub.
 (b) Apply MP grease to the inner flange splines.
 (c) Install the flange to the axle hub.
 (d) Install the 6 cone washers, plate washers and new nuts.

Torque: 33 N·m (335 kgf·cm, 24 ft·lbf)



- (e) Install the bolt in the axle shaft and pull it out.
 (f) Using a snap ring expander, install a new snap ring.
 (g) Remove the bolt.
 (h) Coat inside of the new cap with MP grease.
 (i) Install the cap to the flange.

6. INSTALL BRAKE CALIPER

- (a) Install the brake caliper, 2 bolts and washers.

Torque: 123 N·m (1,250 kgf·cm, 90 ft·lbf)

- (b) Connect the flexible hose and install 2 new gaskets and bolt.

Torque: 30 N·m (310 kgf·cm, 22 ft·lbf)

7. INSTALL FRONT WHEEL

Torque: 209 N·m (2,131 kgf·cm, 154 ft·lbf)

8. BLEED BRAKE LINE (See page BR-10 or BR-5)