




INSPECTION

1. INSPECT LEFT SIDE MIRROR SWITCH CONTINUITY


Switch position	Tester connection	Specified condition
OFF	-	No continuity
UP	3 - 4 7 - 8	Continuity
DOWN	3 - 8 4 - 7	Continuity
LEFT	4 - 9 7 - 8	Continuity
RIGHT	4 - 7 8 - 9	Continuity

2. INSPECT RIGHT SIDE MIRROR SWITCH CONTINUITY

Switch position	Tester connection	Specified condition
OFF	-	No continuity
UP	2 - 4 1 - 7 - 8	Continuity
DOWN	4 - 7 1 - 2 - 8	Continuity
LEFT	4 - 10 1 - 7 - 8	Continuity
RIGHT	4 - 7 1 - 8 - 10	Continuity

If continuity is not as specified, replace the switch.

If continuity is as specified, inspect the switch circuit.




3. INSPECT MIRROR SWITCH CIRCUIT


Disconnect the connector from the switch and inspect the connector on the wire harness side.

Tester connection	Condition	Specified condition
8 - Ground	Constant	Continuity
4 - Ground	Ignition switch position LOCK	No voltage
4 - Ground	Ignition switch position ACC or ON	Battery positive voltage


If the circuit is not as specified, inspect the circuits connected to other parts.

**4. INSPECT INDICATOR LIGHT OPERATION**


Connect the positive (+) lead from the battery to terminal 5 and the negative (-) lead to terminal 6, and check that the indicator light does not light up, replace the switch.

**5. INSPECT MIRROR MOTOR OPERATION**


- (a) Connect the positive (+) lead from the battery to terminal 8 and the negative (-) lead to terminal 7, and check that the mirror turns to the left side.



- (b) Reverse the polarity, and check that the mirror turns to the right side.



- (c) Connect the positive (+) lead from the battery to terminal 6 and the negative (-) lead to terminal 7, and check that the mirror turns upward.



- (d) Reverse the polarity, and check that the mirror turns downward.

If operation is not as specified, replace the mirror assembly.