





INSTALLATION

1. INSTALL RH EXHAUST MANIFOLD TO CYLINDER HEAD

- (a) Place a new gasket on the cylinder head with the white painted marks facing the manifold side.

NOTICE:


Be careful of the installation direction.



- (b) Install the exhaust manifold with 8 new nuts. Uniformly tighten the nuts in several passes.

Torque: 44 N·m (450 kgf·cm, 32 ft·lbf)

- (c) Install the heat insulator with the 4 bolts.




2. INSTALL LH EXHAUST MANIFOLD TO CYLINDER HEAD

- (a) Place a new gasket on the cylinder head with the white painted marks facing the manifold side.

NOTICE:


Be careful of the installation direction.



- (b) Install the exhaust manifold with 8 new nuts. Uniformly tighten the nuts in several passes.

Torque: 44 N·m (450 kgf·cm, 32 ft·lbf)

- (c) Install the heat insulator with the 4 bolts.



3. PLACE CYLINDER HEAD ON CYLINDER BLOCK

- (a) Place 2 new cylinder head gaskets in position on the cylinder block.


HINT:

On the rear side of the cylinder head gasket are marks to distinguish the LH and RH banks, a "R" mark for the RH bank and a "L" mark for the LH bank.

NOTICE:

Be careful of the installation direction.

- (b) Place the 2 cylinder heads in position on the cylinder head gaskets.




4. INSTALL CYLINDER HEAD BOLTS

HINT:


- The cylinder head bolts are tightened in 3 progressive steps (steps (c), (e) and (f)).
 - If any cylinder head bolt is broken or deformed, replace it.
- (a) Apply a light coat of engine oil on the threads and under the heads of the cylinder head bolts.
- (b) Install the plate washer to the cylinder head bolt.
- (c) Install and uniformly tighten the 10 cylinder head bolts on one side of the cylinder head in several passes in the sequence shown, then do the other side as shown.

Torque: 32 N·m (325 kgf·cm, 24 ft·lbf)


If any one of the cylinder head bolts does not meet the torque specification, replace the cylinder head bolt.

**NOTICE:**

Do not drop the plate washer for cylinder head bolt into portion A of the cylinder head. If dropped into portion A, the plate washer will pass through the cylinder head and cylinder block into the oil pan.



- (d) Mark the front of the cylinder head bolt with paint.
- (e) Retighten the cylinder head bolts by 90° in the numerical order shown.
- (f) Retighten the cylinder head bolts by an additional 90°.
- (g) Check that the painted mark is now at a 180° angle to front.


5. INSTALL SPARK PLUGS**6. ASSEMBLE EXHAUST CAMSHAFT**

- (a) Install these parts:
 - (1) Camshaft gear spring
 - (2) Camshaft sub-gear


HINT:

Attach the pins on the gears to the gear spring ends.

- (3) Wave washer




- (b) Using snap ring pliers, install the snap ring.




- (c) Mount the hexagon wrench head portion of the camshaft in a vise.

NOTICE:

Be careful not to damage the camshaft.




- (d) Using SST, align the holes of the camshaft main gear and sub-gear by turning camshaft sub-gear counterclockwise, and temporarily install a service bolt.
SST 09960-10010 (09962-01000, 09963-00500)
- (e) Align the gear teeth of the main gear and sub-gear, and tighten the service bolt.

**7. INSTALL CAMSHAFT HOUSING PLUGS**

- (a) Remove any old packing (FIPG) material.
- (b) Apply seal packing to the camshaft housing plug grooves.

Seal packing:

Part No. 08826-00080 or equivalent




- (c) Install the 2 camshaft housing plugs to the cylinder heads.

8. INSTALL CAMSHAFTS

NOTICE:


Since the thrust clearance of the camshaft is small, the camshaft must be kept level while it is being installed. If the camshaft is not kept level, the portion of the cylinder head receiving the shaft thrust may crack or be damaged, causing the camshaft to seize or break. To avoid this, the following steps should be carried out.




- (a) Set the crankshaft pulley position.
Turn the crankshaft pulley clockwise or counterclockwise, and put the timing mark of the crankshaft pulley in line with the centers of the crankshaft pulley bolt and idler pulley bolt.

NOTICE:

Having the crankshaft pulley at the wrong angle can cause the piston head and valve head to come into contact with each other when you install the camshaft, causing damage. So always set the crankshaft pulley at the correct angle.



- (b) Install the RH camshafts.
- (1) Apply MP grease to the thrust portion of the intake and exhaust camshafts.
 - (2) Place the intake and exhaust camshafts.
 - (3) Set the timing mark (1 dot mark) of the camshaft main gear at approx. 10° angle.



- (4) Remove any old packing (FIPG) material from front bearing cap.
- (5) Apply seal packing to the front bearing cap as shown in the illustration.


Seal packing:

Part No. 08826-00080 or equivalent

- Install a nozzle that has been cut to a 1.5 mm (0.06 in.) opening.
- Parts must be assembled within 5 minutes of application. Otherwise the material must be removed and reapplied.
- Immediately remove nozzle from the tube and reinstall cap.

NOTICE:

Do not apply seal packing to the front bearing cap grooves.



- (6) Install the front bearing cap.


HINT:

Installing the front bearing cap will determine the thrust portion of the camshaft.


- (7) Install the other bearing cap in the sequence shown with the arrow mark facing forward.

HINT:

Align the arrow marks at the front and rear of the cylinder head with the mark on the bearing cap.



- (8) Push in the camshaft oil seal.



- (9) Apply a light coat of engine oil on the threads and under the heads (D and E) of the bearing cap bolts.

HINT:

Do not apply engine oil under the heads of the bearing cap bolt (A), (B) and (C).

- (10) Install the oil feed pipe and the 22 bearing cap bolts as shown.

HINT:

Each bolt length is indicated in the illustration.

Bolt length:

94 mm (3.70 in.) for A

72 mm (2.83 in.) for B

25 mm (0.98 in.) for C

52 mm (2.05 in.) for D

38 mm (1.50 in.) for E



- (11) Uniformly tighten the 22 bearing cap bolts in several passes, in the sequence shown.

Torque:**Bolt C:**


7.5 N·m (80 kgf·cm, 69 in.·lbf)

Others


16 N·m (160 kgf·cm, 12 ft·lbf)



- (12) Boring the service bolt installed in the driven sub-gear upward by turning the hexagon wrench head portion of the camshaft with a wrench.
- (13) Remove the service bolt.



- (c) Install the LH camshafts.
- (1) Apply MP grease to the thrust portion of the intake and exhaust camshafts.
 - (2) Place the intake and exhaust camshafts.
 - (3) Engage the intake to the exhaust gear by meeting the timing marks (2 dot marks) on each gear.



- (4) Remove any old packing (FIPG) material.
- (5) Apply seal packing to the front bearing cap.


Seal packing:

Part No. 08826-00080 or equivalent

- Install a nozzle that has been cut to a 1.5 mm (0.06 in.) opening.
- Parts must be assembled within 5 minutes of application. Otherwise the material must be removed and reapplied.
- Immediately remove nozzle from the tube and reinstall cap.

NOTICE:

Do not apply seal packing to the front bearing cap grooves.



- (6) Install the front bearing cap.


HINT:

Installing the front bearing cap will determine the thrust portion of the camshaft.


- (7) Install the other bearing cap in the sequence shown with the arrow mark facing forward.

HINT:

Align the arrow marks at the front and rear of the cylinder head with the mark on the bearing cap.



- (8) Push in the camshaft oil seal.



- (9) Apply a light coat of engine oil on the threads and under the heads (D and E) of the bearing cap bolts.

HINT:

Do not apply engine oil under the heads of the bearing cap bolt (A), (B) and (C).


- (10) Install the oil feed pipe and the 22 bearing cap bolts as shown.

HINT:

Each bolt length is indicated in the illustration.

Bolt length:

- 94 mm (3.70 in.) for A
- 72 mm (2.83 in.) for B
- 25 mm (0.98 in.) for C
- 52 mm (2.05 in.) for D
- 38 mm (1.50 in.) for E



- (11) Uniformly tighten the 22 bearing cap bolts in several passes, in the sequence shown.


Torque:

Bolt C:

7.5 N·m (80 kgf·cm, 69 in·lbf)

Others

16 N·m (160 kgf·cm, 12 ft·lbf)




- (12) Boring the service bolt installed in the driven sub-gear upward by turning the hexagon wrench head portion of the camshaft with a wrench.

- (13) Remove the service bolt.

9. CHECK AND ADJUST VALVE CLEARANCE

(See page [EM-4](#))

Turn the camshaft and position the cam lobe upward, and check and adjust the valve clearance.




10. INSTALL SEMI-CIRCULAR PLUGS


- (a) Remove any old packing (FIPG) material.
- (b) Apply seal packing to the semi-circular plug grooves.

Seal packing:

Part No. 08826-00080 or equivalent



- (c) Install the 4 semi-circular plugs to the cylinder heads.



11. INSTALL CYLINDER HEAD COVER

- (a) Remove any old packing (FIPG) material.
 (b) Apply seal packing to the cylinder heads as shown in the illustration.

Seal packing:

Part No. 08826-00080 or equivalent


- (c) Install the gasket to the cylinder head cover.
 (d) Install the seal washer to the bolt.
 (e) Install the cylinder head cover with the 18 bolts. Uniformly tighten the bolts in several passes. Install the 2 cylinder head covers.

Torque: 6.0 N·m (60 kgf·cm, 53 in·lbf)

12. INSTALL ENGINE HANGERS

Torque: 37 N·m (380 kgf·cm, 27 ft·lbf)


13. INSTALL OIL DIPSTICK AND GUIDE FOR ENGINE



14. INSTALL REAR WATER BYPASS JOINT


- (a) Install 2 new gaskets to the cylinder head.
 (b) Install the 4 nuts holding the water bypass joint to the cylinder heads. Alternately tighten the nuts.

Torque: 18 N·m (185 kgf·cm, 13 ft·lbf)

**15. INSTALL FRONT WATER BYPASS JOINT**

- (a) Install 2 new gaskets and the water bypass joint with the 4 nuts. Alternately tighten the nuts.


Torque: 18 N·m (185 kgf·cm, 13 ft·lbf)

16. INSTALL WATER INLET AND INLET HOUSING ASSEMBLY (See page CO-8)**17. INSTALL INTAKE MANIFOLD ASSEMBLY**

- (a) Place 2 new gaskets on the cylinder heads with white painted mark facing upward.


NOTICE:

- **Align the port holes of the gasket and cylinder head.**
- **Be careful of the installation direction.**




- (b) Place the intake manifold assembly on the cylinder heads.
- (c) Install and uniformly tighten the 6 bolts and 4 nuts in several passes.


Torque: 18 N·m (185 kgf·cm, 13 ft·lbf)




- (d) Install the EVAP pipe to the intake manifold with the 2 bolts.




- (e) Connect the wire protector to the intake manifold with the 2 bolts.
- (f) Install the engine wire to the engine hanger.
- (g) Install the engine wire to the LH No.1 timing belt rear plate.
- (h) Install the engine wire to the bracket.




- (i) Connect the wire protector to the rear water bypass joint and RH cylinder head with the 2 bolts.
- (j) Install the 2 grounds cables to the RH and LH cylinder head.
- (k) Install the guide for A/T bracket to the LH cylinder head.



- (l) Connect the 2 wire clamp to the wire clamp bracket on the RH delivery pipe.



- (m) Connect these hoses:
 - Fuel pressure regulator vacuum hose to the fuel pressure regulator pipe.
 - PCV hose to PCV valve on LH cylinder head
 - EVAP hose (from charcoal canister) to VSV for EVAP
 - EVAP hose (from charcoal canister) to EVAP pipe on the intake manifold
 - EVAP hose (from intake air connector) to EVAP pipe on the intake manifold
 - PS air hose to intake manifold



- (n) No.1 water bypass hose (from water inlet housing) from throttle body
- (o) Connect the 2 wire clamp to the throttle body.
- (p) Connect these connectors:
 - Throttle position sensor connector
 - Accelerator pedal position sensor connector
 - Throttle motor connector
 - VSV connector for EVAP
 - 8 injector connectors
 - ECT sensor
 - Water sender gauge
 - 8 ignition coil connector
 - 2 oxygen sensor connector
- (q) Connect the accelerator cable.

18. CONNECT FUEL INLET HOSE

(See page [SF-24](#))

19. INSTALL TIMING BELT REAR PLATES

- (a) Install the RH timing belt rear plates.
 - Install the No.1 timing belt rear plate to the cylinder head with the 3 bolts and stud bolt.

Torque: 7.5 N·m (80 kgf·cm, 66 in.·lbf)

- (b) Install the LH timing belt rear plates.
 - (1) Connect the wire clamp to the No.1 timing belt rear plate.
 - (2) Install the No.1 timing belt rear plate to the cylinder head with the 3 bolts.

Torque: 7.5 N·m (80 kgf·cm, 66 in.·lbf)

20. INSTALL V-BANK COVER

Install the 3 V-bank covers.

Torque: 7.5 N·m (80 kgf·cm, 69 in.·lbf)

21. INSTALL IGNITION COILS

(See page [IG-6](#))

22. INSTALL OIL DIPSTICK AND GUIDE FOR A/T

23. INSTALL FRONT EXHAUST PIPE

(See page [EM-113](#))

24. INSTALL PS PUMP

(See page [EM-80](#))

25. INSTALL CAMSHAFT POSITION SENSOR

(See page [IG-10](#))

26. INSTALL CAMSHAFT TIMING PULLEYS

(See page [EM-22](#))

27. CONNECT TIMING BELT TO CAMSHAFT TIMING PULLEYS

(See page [EM-22](#))

28. CHECK ENGINE OIL LEVEL