

TROUBLESHOOTING

TR030-01

PROBLEM SYMPTOMS TABLE

Use the table below to help you find the cause of the problem. The numbers indicate the priority of the likely cause of the problem. Check each part in order. If necessary, replace these parts.

Symptom	Suspect Area	See page
Noise	1. Oil (Level low) 2. Oil (Wrong) 3. Transfer faulty	TR-4 TR-4 TR-7
Oil leakage	1. Oil (Level too high) 2. Gasket (Damaged) 3. Oil seal (Worn or damaged) 4. O-ring (Worn or damaged)	TR-4 TR-7 TR-7 –
Transfer corner braking	Center differential or transfer faulty	TR-7