

ENGINE

HOW TO PROCEED WITH TROUBLESHOOTING

DI078-09

Troubleshoot in accordance with the procedure on the following page.

