

REMOVAL

NOTICE:

Before starting the work, make sure that the ignition switch is OFF and depress the brake pedal more than 40 times.

HINT:

When a pressure in power supply system is released, reaction force becomes light and stroke becomes longer.

NOTICE:

- As high pressure is applied to the brake actuator tube No. 1, never deform it.
- Until the work is over, do not turn the ignition switch ON.

1. DRAW OUT FLUID WITH SYRINGE

NOTICE:

Do not let brake fluid remain on a painted surface. Wash it off immediately.


2. REMOVE SCUFF PLATE, COWL SIDE TRIM, LOWER NO. 1 PANEL, LH LOWER PANEL AND NO. 2 HEATER TO REGISTER DUCT (See page BO-13)

3. REMOVE ABS OR ABS & TRC & VSC ECU


Remove the 2 nuts and ABS or ABS & TRC & VSC ECU.

Torque: 5.0 N·m (51 kgf·cm, 44 in·lbf)


4. REMOVE CHARCOAL CANISTER




5. w/ ABS only: DISCONNECT 4 CONNECTORS




6. w/ ABS & TRC & VSC only: DISCONNECT 5 CONNECTORS



- 7. w/ ABS only:**
DISCONNECT BRAKE LINES
Using SST, disconnect the 3 brake lines.
SST 09023-00100
Torque: 15 N·m (155 kgf·cm, 11 ft·lbf)



- 8. w/ ABS & TRC & VSC only:**
DISCONNECT BRAKE LINES
Using SST, disconnect the 4 brake lines.
SST 09023-00100
Torque: 15 N·m (155 kgf·cm, 11 ft·lbf)
- 9. REMOVE CLIP AND CLEVIS PIN**



- 10. REMOVE HYDRAULIC BRAKE BOOSTER ASSEMBLY**
(a) Remove the 4 booster installation nuts.
Torque: 15 N·m (155 kgf·cm, 11 ft·lbf)
(b) Remove the booster assembly and gasket.