

|            |              |                                                 |
|------------|--------------|-------------------------------------------------|
| <b>DTC</b> | <b>P1780</b> | <b>Park/Neutral Position Switch Malfunction</b> |
|------------|--------------|-------------------------------------------------|


## CIRCUIT DESCRIPTION

The park/neutral position switch detects the shift lever position and sends signals to the ECM.

The ECM receives signals (NSW, R, D, 2 and L) from the park/neutral position switch. When the signal is not sent to the ECM from the park/neutral position switch, the ECM judges that the shift lever is in D position.

| DTC No. | DTC Detection Condition                                                                                                                                                                                                                  | Trouble Area                                                                                                                                             |
|---------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|
| P1780   | 2 or more switches are ON simultaneously for N, 2 and L positions.<br>(2-trip detection logic)                                                                                                                                           | <ul style="list-style-type: none"> <li>• Short in park/neutral position switch circuit</li> <li>• Park/neutral position switch</li> <li>• ECM</li> </ul> |
|         | When driving under conditions (a) and (b) for 30 seconds or more, the park/neutral position switch is ON (N position).<br>(2-trip detection logic)<br>(a) Vehicle speed: 70 km/h (44 mph) or more<br>(b) Engine speed: 1,500 – 2,500 rpm |                                                                                                                                                          |

## WIRING DIAGRAM



D03060

## INSPECTION PROCEDURE

## 1 Read PNP, REVERSE, 2ND and LOW signals.

**When using TOYOTA hand-held tester:**

**PREPARATION:**

- Connect a TOYOTA hand-held tester to the DLC3.
- Turn the ignition switch ON and TOYOTA hand-held tester main switch ON.

**CHECK:**

Shift lever into the P, R, D, N, 2 and L positions, and read the PNP, REVERSE, 2ND and LOW signals on the TOYOTA hand-held tester.

**OK:**

| Shift position | Signal           |
|----------------|------------------|
| 2              | 2ND OFF → ON     |
| L              | LOW OFF → ON     |
| R              | REVERSE OFF → ON |
| P,N            | PNP SW OFF → ON  |

**When not using TOYOTA hand-held tester:**

**PREPARATION:**

Turn the ignition switch ON.

**CHECK:**

Measure voltage between terminals NSW, R, D, 2 and L of ECM and body ground when the shift lever is shifted to the following positions.

**OK:**

| Position | NSW-Body ground | R-Body ground | D-Body ground | 2-Body ground | L-Body ground |
|----------|-----------------|---------------|---------------|---------------|---------------|
| P,N      | 0 V             | 0 V           | 0 V           | 0 V           | 0 V           |
| R        | 9 – 14 V*       | 7.5 – 14 V*   | 0 V           | 0 V           | 0 V           |
| D        | 9 – 14 V        | 0 V           | 7.5 – 14 V    | 0 V           | 0 V           |
| 2        | 9 – 14 V        | 0 V           | 0 V           | 7.5 – 14 V    | 0 V           |
| L        | 9 – 14 V        | 0 V           | 0 V           | 0 V           | 7.5 – 14 V    |


**HINT:**

The voltage will drop slightly due to lighting up the back up light.

**OK**


**Check and replace the ECM (See page IN-34).**

**NG**



2

# Check park/neutral position switch.



N

D06561

## **PREPARATION:**

Remove the park/neutral position switch connector.

## **CHECK:**

Check continuity between each terminal shown below when the shift lever is moved to each position.

## **OK:**

| Shift Position | Terminal No. to continuity |       |
|----------------|----------------------------|-------|
| P              | 6 - 9                      | 1 - 3 |
| R              | 2 - 3                      | -     |
| N              | 6 - 9                      | 3 - 5 |
| D              | 3 - 7                      | -     |
| 2              | 3 - 4                      | -     |
| L              | 3 - 8                      | -     |

NG

Replace the park/neutral position switch.

OK

Repair or replace harness and connector between battery and park/neutral position switch, park/neutral position switch and ECM (See page [IN-34](#)).