


## Sensor Power Source Circuit

### CIRCUIT DESCRIPTION


Power to the position sensor is output from ECU.

### WIRING DIAGRAM



## INSPECTION PROCEDURE

- |   |                                                                                     |
|---|-------------------------------------------------------------------------------------|
| 1 | <b>Check voltage between terminals S5V1 and SG1, S5V2 and SG2 of ECU connector.</b> |
|---|-------------------------------------------------------------------------------------|

**PREPARATION:**

Remove ECU with connectors still connected.

**CHECK:**

Measure voltage between terminals S5V1 and SG1, S5V2 and SG2 of ECU connector.

**OK:**

**Voltage: 4.5 – 5.5 V**

**NG**

**Go to step 3.**

**OK**

- |   |                                                                                                                       |
|---|-----------------------------------------------------------------------------------------------------------------------|
| 2 | <b>Check for open circuit in harness and connector between terminals S5V1 and SG1, S5V2 and SG2 of ECU connector.</b> |
|---|-----------------------------------------------------------------------------------------------------------------------|

**NG**

**Repair or replace harness or connector.**

**OK**

**Proceed to next circuit inspection shown on the problem symptoms table (See page [DI-453](#)).**

- |   |                                                                                                          |
|---|----------------------------------------------------------------------------------------------------------|
| 3 | <b>Check for short circuit in harness between terminals S5V1 and SG1, S5V2 and SG2 of ECU connector.</b> |
|---|----------------------------------------------------------------------------------------------------------|

**NG**

**Repair or replace harness or connector.**

**OK**

**Check and replace tilt and telescopic ECU.**