


15. Touch switch does not function. (Navigation screen only)

INSPECTION PROCEDURE


1	Display check mode (Touch switch, Touch point screen).
---	--

NG	Replace the multi-display.
----	----------------------------



2	Check "AVC-LAN communication circuit" (See page DI-104).
---	--

NG	Replace or repair AVC-LAN circuit.
----	------------------------------------



Replace the navigation ECU.
