

17. Panel switch does not function. (Navigation screen only)

INSPECTION PROCEDURE

1 Display check mode (Panel switch check screen).

NG

Replace the multi display.

OK

2 Check "AVC-LAN communication circuit" ([See page DI-104](#)).

NG

Replace or repair AVC-LAN circuit.

OK

Replace the navigation ECU.