

24. Driving direction is opposite to moving direction of vehicle position mark.

INSPECTION PROCEDURE

1 Navigation check mode (vehicle signal check mode REV).

OK

Replace the navigation ECU.

NG

2 Check the navigation ECU.

CHECK:

Check terminal REV.

OK:

REV: See "Navigation ECU" of "TERMINAL OF ECU".

OK

Replace the navigation ECU.

NG

Replace or repair wire harness.