

10. Sound of radio, cassette tape or CD only cannot be heard from speaker.

INSPECTION PROCEDURE

1	Check the radio receiver assembly.
---	------------------------------------

PREPARATION:

Disconnect the radio receiver assembly connector.

CHECK:

Check voltage terminals +B.

OK:

+B: 10 – 14 V

CHECK:

Check voltage terminal ACC when turn ignition switch ACC or ON position.

OK:

ACC: 10 – 14 V

CHECK:

Check continuity terminal GND.

OK:

GND: Continuity

NG

Replace or repair wire harness or connector.

OK

Replace the radio receiver assembly.