




DISASSEMBLY

NOTICE:

When using a vise, do not overtighten it.

1. REMOVE NO. 2 LOWER COVER

Remove the 2 nuts and lower side No. 2 lower cover.

2. REMOVE INTERMEDIATE SHAFT ASSEMBLY


- Place matchmarks on the intermediate shaft assembly and main shaft assembly.
- Remove the bolt and intermediate shaft assembly with the upper side No. 2 lower cover.
- Remove the thrust stopper from the main shaft assembly.

3. REMOVE TRANSPONDER KEY COIL WITH KEY CYLINDER LAMP ASSEMBLY

Remove the screw and transponder key coil with key cylinder lamp assembly.

4. REMOVE KEY CYLINDER LAMP ASSEMBLY

Remove the key cylinder lamp assembly from the transponder key coil.




5. REMOVE COLUMN UPPER BRACKET AND COLUMN UPPER CLAMP

- Using a centering punch, mark the center of the 2 tapered-head bolts.
- Using a 3-4 mm (0.12-0.16 in.) drill, drill into the 2 bolts.
- Using a screw extractor, remove the 2 bolts, column upper bracket and column upper clamp.

6. REMOVE COLUMN TUBE SUPPORT

- Remove the bolt.
- Remove the column tube support with tube attachment.
- Remove the tube attachment from the column tube support.




7. REMOVE 2 ENERGY ABSORBING PLATES

- Using pliers, remove the 2 energy absorbing clips.
- Remove the 2 energy absorbing plates and 2 energy absorbing guides.

8. REMOVE 4 TENSION SPRINGS

HINT:


Remove the springs with the tilt function at maximum tilt up.

**9. REMOVE TILT LEVER**

- (a) Using a screwdriver, remove the spring nut.
- (b) Remove the tilt lever.
- (c) Remove the 2 bushings from the column upper tube.

10. REMOVE TILT LEVER LINK**11. REMOVE COLUMN UPPER TUBE WITH MAIN SHAFT ASSEMBLY**

- (a) Using a hexagon wrench, remove the 2 tilt steering bolts.
- (b) Remove the upper tube with the main shaft assembly from the column tube.

12. REMOVE TILT LEVER RETAINER**13. REMOVE MAIN SHAFT ASSEMBLY**

- (a) Using SST, compress the compression spring.
SST 09950-40011 (09958-04011)


NOTICE:

Do not bend the universal joint of the shaft more than 20°.


- (b) Using a snap ring expander, remove the snap ring from the shaft.
- (c) Remove the shaft assembly from the column upper tube.
- (d) Remove the compression spring and bearing thrust collar from the shaft.

14. REMOVE TURN SIGNAL BRACKET

Remove the 2 bolts and turn signal bracket.

**15. REMOVE TILT STEERING PAWL**

- (a) Using a pin punch and hammer, tap out the tilt steering No. 2 shaft.
- (b) Remove the pawl from the column upper tube.
- (c) Remove the pin from the pawl.

**16. REMOVE BUSHING**

Using a screwdriver, tap out the bushing.