


# REAR DIFFERENTIAL LOCK

FROM POWER SOURCE SYSTEM (SEE PAGE 64)





# REAR DIFFERENTIAL LOCK

## SYSTEM OUTLINE

This system locks/frees the rear differential by operation of the rear diff. lock SW.

- \* With the ignition SW turned on, rear diff. lock SW on, transfer lever in L, and the speed below 8 km/h (5 mph), the relay installed in the rear diff. lock control ECU is turned on through control of the rear diff. lock control ECU, and the current flows from DIFF fuse to rear diff. lock control ECU TERMINAL 5 to TERMINAL 3 to rear diff. lock motor TERMINAL 3 to TERMINAL 2 to rear diff. lock control ECU TERMINAL 2 to TERMINAL 7 to GROUND. As a result, the rear differential lock operates and the rear differential is locked. At the same time, the detection SW (Rear diff. lock ) is turned on, and the rear diff. indicator light in the combination meter lights up.
- \* When the rear diff. lock SW is turned to off from on, the relay installed in the rear diff. lock control ECU is turned on through control of the rear diff. lock control ECU, and the current flows from DIFF fuse to rear diff. lock control ECU TERMINAL 5 to TERMINAL 2 to rear diff. lock motor TERMINAL 2 to TERMINAL 3 to rear diff. lock control ECU TERMINAL 3 to TERMINAL 7 to GROUND. As a result, the rear differential lock operates and the rear differential is made free. At the same time, the detection SW (Rear diff. lock) is turned off, and the rear diff. indicator light in the combination meter is turned off.

The rear diff. indicator light blinks under the following conditions :

- \* When the rear diff. lock SW is turned on with the ignition SW on and the transfer lever at a position other than L.
- \* When the rear diff. lock SW is turned on at a speed over 8 km/h (5 mph), with the ignition SW on and the transfer position lever at L position.
- \* When the rear diff. lock motor is operating the rear differential to free from lock, and the detection SW (Rear diff. lock ) is off.

## SERVICE HINTS

### R2 REAR DIFF. LOCK CONTROL ECU

5-GROUND : Approx. 12 volts with ignition SW at **ON** or **ST** position

4-GROUND : Approx. 12 volts with ignition SW at **ON** or **ST** position and rear diff. lock SW at **ON** position

7-GROUND : Always continuity

## : PARTS LOCATION

| Code | See Page | Code | See Page | Code | See Page |
|------|----------|------|----------|------|----------|
| A22  | 40       | D5   | 38       | J18  | 41       |
| C5   | 40       | D9   | 42       | R2   | 41       |
| C12  | A 40     | E8   | 40       | R3   | 41       |
| C13  | B 40     | J14  | 41       | R18  | 43       |
| C14  | C 40     | J17  | 41       | V2   | 39       |

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

| Code | See Page | Junction Block and Wire Harness (Connector Location)                      |
|------|----------|---------------------------------------------------------------------------|
| 2B   | 26       | Dash Wire and Cowl Side J/B LH (Left Kick Panel)                          |
| 2D   |          |                                                                           |
| 2P   | 28       | Instrument Panel Integration Wire and Cowl Side J/B LH (Left Kick Panel)  |
| 3C   | 32       | Dash Wire and Cowl Side J/B RH (Right Kick Panel)                         |
| 3E   | 32       | Floor No.2 Wire and Cowl Side J/B RH (Right Kick Panel)                   |
| 3I   | 32       | Instrument Panel Integration Wire and Cowl Side J/B RH (Right Kick Panel) |

## : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

| Code | See Page | Joining Wire Harness and Wire Harness (Connector Location)                                  |
|------|----------|---------------------------------------------------------------------------------------------|
| EB1  | 46       | Engine Wire and Transmission Wire (On the Transmission)                                     |
| IF1  | 48       | Instrument Panel Integration Wire and Instrument Panel Wire (Left Side of Instrument Panel) |
| IG3  | 50       | Engine Room No.2 Wire and Dash Wire (Behind the Combination Meter)                          |
| IN1  | 52       | Engine Wire and Dash Wire (Behind the Glove Box)                                            |
| IV1  | 54       | Dash Wire and Floor No.2 Wire (Behind the Glove Box)                                        |
| IX1  | 54       | Instrument Panel Integration Wire and Engine Wire (Behind the Glove Box)                    |
| IW2  | 54       | Engine Room No.2 Wire and Dash Wire (Behind the Glove Box)                                  |
| BD2  | 56       | Floor No.3 Wire and Floor Wire (Left Rear Side Quarter Panel)                               |
| BF1  | 56       | Frame Wire and Floor No.3 Wire (Left Side of Rear Floor Crossmember)                        |
| BL1  | 58       | Floor No.2 Wire and Floor No.3 Wire (Right Side of Rear Floor Crossmember)                  |
| BL3  |          |                                                                                             |

**: GROUND POINTS**

| Code | See Page           | Ground Points Location                      |
|------|--------------------|---------------------------------------------|
| EC   | <a href="#">46</a> | Rear Bank of Right Cylinder Head            |
| IG   | <a href="#">48</a> | Set Bolt of Cowl Side J/B LH                |
| BK   | <a href="#">56</a> | Front Side Under the Front Passenger's Seat |
| BM   | <a href="#">56</a> | Left Rear Side Quarter Panel                |

**: SPLICE POINTS**

| Code | See Page           | Wire Harness with Splice Points | Code | See Page           | Wire Harness with Splice Points |
|------|--------------------|---------------------------------|------|--------------------|---------------------------------|
| E8   | <a href="#">46</a> | Transmission Wire               | B12  | <a href="#">58</a> | Frame Wire                      |
| I15  | <a href="#">50</a> | Dash Wire                       | B16  | <a href="#">58</a> | Floor No.3 Wire                 |