




INSPECTION

INSPECT INTAKE AIR CONTROL VALVE

- (a) Apply vacuum (less than 60 kPa (450 mmHg, 18 in.Hg) to the actuator, check that the actuator rod moves and close the valves.
- (b) One minute after applying the vacuum in (a), check that the actuator rod does not return.

If the operation is not as specified, replace the intake air control valve.