

I25541


INSPECTION

1. INSPECT POWER AMPLIFIER CIRCUIT

Disconnect the connector from power amplifier and inspect the connector on the wire harness side.

Tester connection	Condition	Specified condition
12 – Ground	Constant	Continuity
13 – Ground	Constant	Continuity
7 – Ground	Constant	Battery voltage
16 – Ground	Constant	Battery voltage

If the circuit is not as specified, inspect the circuits connected to other parts.



T


I25540

2. INSPECT REAR SEAT AUDIO CIRCUIT

Disconnect the connector from RSA controller and inspect the connector on the wire harness side.

Tester connection	Condition	Specified condition
17 – Ground	Constant	Continuity
24 – Ground	Ignition switch LOCK	No voltage
24 – Ground	Ignition switch ACC or ON	Battery voltage
12 – Ground	Constant	Battery voltage

If the circuit is not as specified, inspect the circuits connected to other parts.



3. INSPECT RADIO RECEIVER ASSEMBLY CIRCUIT

Disconnect the connectors from the radio receiver assembly, and inspect the connector on the wire harness side.

Tester connection	Condition	Specified condition
A20 – Ground	Constant	Continuity
A1 – Ground	Constant	Battery voltage
A11 – Ground	Ignition switch LOCK	No voltage
A11 – Ground	Ignition switch ACC or ON	Battery voltage

If the circuit is not as specified, inspect the circuits connected to other parts.

HINT:

Check the wire harness between radio receiver assembly and the CD auto changer, between radio receiver assembly and power amplifier.



Disconnect the connectors from the steering pad switch, and inspect the connector on the wire harness side.

If the circuit is not as specified, inspect the circuits connected to other parts.