

DTC	P0711	Transmission Fluid Temperature Sensor "A" Performance
------------	--------------	--

CIRCUIT DESCRIPTION

The ATF temperature sensor converts fluid temperature into a resistance value which is input into the Engine and ECT ECU.


DTC No.	DTC Detecting Condition	Trouble Area
P0711	Both (a) and (b) are detected: (2-trip detection logic) (a) After 12 sec. of engine start, temp. of atmosphere and that of engine coolant is more than -10°C (b) After normal driving for over 20 min. and 10 km, ATF temp. is less than 10°C	• Open or short in ATF temperature sensor No. 1 circuit • ATF temperature sensor No. 1 • Engine and ECT ECU

WIRING DIAGRAM

See page DI-37.

INSPECTION PROCEDURE

1	Check transmission wire.
----------	---------------------------------



PREPARATION:

Disconnect the transmission wire connector from the transmission.

CHECK:

Measure resistance between terminals OT+ and OT- of the transmission wire connector and body ground.

OK:

Resistance: 1 MΩ or higher

CHECK:

Measure the resistance between terminals OT+ and OT-.

OK:


Temperature: °C (°F)	Resistance: kΩ
10 (50)	6.4
110 (230)	0.2

NG

Replace the transmission wire (ATF temperature sensor).

OK

2 Measure resistance between terminal THO1 and E2 of Engine and ECT ECU connector.



PREPARATION:

- (a) Connect the transmission wire connector.
- (b) Disconnect the connector of the Engine and ECT ECU.

CHECK:

Measure the resistance between terminals THO1 and E2.

OK:

Temperature: °C (°F)	Resistance: kΩ
10 (50)	6.4
110 (230)	0.2

CHECK:

Measure resistance between terminals THO1 and E2 of the Engine and ECT ECU connector and body ground.

OK:

Resistance: 1 MΩ or higher

NG

Repair or replace the harness or connector
(See page IN-38).

OK

Check and replace the Engine and ECT ECU
(See page IN-38).