


DTC	P0778/63	Pressure Control Solenoid "B" Electrical (Shift Solenoid Valve SL2)
-----	----------	--

CIRCUIT DESCRIPTION

See page DI-49.


DTC No.	DTC Detection Condition	Trouble Area
P0778/63	Engine and ECT ECU checks for an open or short circuit in shift solenoid valves SL2 (1-trip detection logic) (a) When solenoid is energized, duty ratio exceed 75% (b) When solenoid is not energized, duty ratio is less than 3%	• Open or short in shift solenoid valve SL2 circuit • Shift solenoid valve SL2 • Engine and ECT ECU

WIRING DIAGRAM



INSPECTION PROCEDURE

1 Check transmission wire.

**PREPARATION:**

Disconnect the transmission wire connector.

CHECK:

Measure resistance between SL2⁺ and SL2⁻ of transmission wire.

OK:

Resistance: 5.0 – 5.6 Ω at 20°C (68°F)

CHECK:

Measure resistance between terminals SL2⁺ and SL2⁻ of the transmission wire connector and body ground.


OK:

Resistance: 1 M Ω or higher

NG

Go to step 3.

OK

2 Measure resistance between terminal SL2⁺ and SL2⁻ of Engine and ECT ECU connector.**PREPARATION:**

(a) Connect the transmission wire connector.

(b) Disconnect the connector of the Engine and ECT ECU.

CHECK:

Measure resistance between terminals SL2⁺ and SL2⁻ of Engine and ECT ECU connector.

OK:

Resistance: 5.0 – 5.6 Ω at 20°C (68°F)

CHECK:

Measure resistance between terminals SL2⁺ and SL2⁻ of the Engine and ECT ECU connector and body ground.

OK:

Resistance: 1 M Ω or higher


NG

Repair or replace the harness or connector
(See page IN-38).

OK

Check and replace the Engine and ECT ECU
(See page IN-38).

3 Check shift solenoid valve SL2.



D12795

PREPARATION:

- Jack up the vehicle.
- Remove the oil pan.
- Remove the shift solenoid valve SL2.

CHECK:

- Measure the resistance between terminals 1 and 2 of solenoid connector.

Standard: 5.0 – 5.6 Ω at 20°C (68°F)

- Connect the positive (+) lead with an 21 W bulb to terminal 2 of solenoid connector and negative (–) lead to terminal 1 of the solenoid valve connector, then check the movement of the valve.

Standard: Solenoid sounds operation noise.

OK:

Standard

NG

**Replace the shift solenoid valve SL2
(See page AT-8).**

OK

**Repair or replace the transmission wire
(See page AT-6).**