


DTC	C1268 / 68	Transfer L4 Position Switch Circuit
-----	------------	-------------------------------------

CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1268 / 68	Open or short circuit in transfer L4 position switch.	- Transfer L4 position switch - Transfer L4 position switch circuit

WIRING DIAGRAM




N

F17714

INSPECTION PROCEDURE

- 1 Check voltage between terminal EXI2 of skid control ECU and body ground.



PREPARATION:

Remove skid control ECU with connectors still connected.

CHECK:

- (a) Turn the ignition switch ON.
- (b) Measure voltage between terminal EXI2 of skid control ECU and body ground when transfer in L4 position.

OK:

Voltage: 10 – 14 V

OK

Proceed to next circuit inspection shown in problem symptoms chart ([See page DI-206](#)).

NG

- 2 Check transfer L4 position switch (Full-time 4WD type: See Pub. No. RM616E on page TR-53).

NG

Replace transfer L4 position switch.

OK

- 3 Check for open or short circuit in harness and connector between transfer L4 position switch and skid control ECU ([See page IN-38](#)).

NG

Repair or replace harness or connector.

OK

4

Check for open or short circuit in harness and connector between skid control ECU and engine and ECT ECU ([See page IN-38](#)).

NG

Repair or replace harness or connector.

OK

Check and replace skid control ECU.