


DTC	C1336 / 39	Zero Point Calibration of Deceleration Sensor Undone
------------	-------------------	---

CIRCUIT DESCRIPTION


DTC No.	DTC Detecting Condition	Trouble Area
C1236 / 39	When any of following 1. through 2. is detected: 1. In TEST mode, the shift lever is shifted to other than P range with 2 sec. after ECU terminal IG1 is turned ON for the first time. 2. When the deceleration sensor zero point recorded in ECU is deleted.	• Deceleration sensor • Deceleration sensor circuit • Neutral start switch circuit (R range)

WIRING DIAGRAM



INSPECTION PROCEDURE

1	Perform zero point calibration of the yaw rate (deceleration) sensor (See page DI-185).
---	---



2 Is DTC still output?


Check DTC on [page DI-185](#).

NO

End.

YES

3 Check yaw rate (deceleration) sensor.



PREPARATION:

- Connect 3 dry batteries of 1.5 V in series.
- Connect VYS terminal to the batteries' positive (+) terminal, and GYAW terminal to the batteries' negative (-) terminal. Apply about 4.5 V between VYS and GYAW terminals.

NOTICE:

Do not apply voltage of 6 V or more to terminals VYS and GYAW.

CHECK:

Check the output voltage of GL1 and GL2 terminals when the sensor is tilted forward and rearward.

OK:

Symbols	Condition	Standard Value
GL1	Horizontal	About 2.3 V
GL1	Lean rearward	1.0 V – about 2.3 V
GL1	Lean forward	About 2.3 V – 3.5 V
GL2	Horizontal	About 2.3 V
GL2	Lean rearward	About 2.3 V – 3.5 V
GL2	Lean forward	1.0 V – about 2.3 V

HINT:

- If the sensor is tilted too much it may show the wrong value.
- If dropped, the sensor should be replaced with a new one.
- The sensor removed from the vehicle should not be placed upside down.

NG

Replace yaw rate sensor.

OK

4

Check for open or short circuit in harness and connector between yaw rate (deceleration) sensor and skid control ECU ([See page IN-38](#)).

NG

Repair or replace harness or connector.

OK

Check and replace skid control ECU.