

PARTS LOCATION

Sliding Roof Control Gear Assembly with ECU

Sliding Roof Control Switch

Ignition Switch

Driver Side Junction Block

- POWER M-Fuse
- DOME Fuse
- Power Main Relay