

PROBLEM SYMPTOMS TABLE

LIGHTING SYSTEM:

Symptom	Suspect Area	See page
Headlight does not light up. (Low beam)	1. Light control switch circuit 2. Headlight relay circuit 3. Combination switch 4. Body ECU	DI-1019 DI-1030 BE-23 –
Headlight system does not operate. (HI beam or Flash)	1. Headlight dimmer switch circuit 2. Light control switch circuit 3. Combination switch 4. Body ECU	DI-1022 DI-1019 BE-23 –
Taillight system does not light up.	1. Taillight relay circuit 2. Light control switch circuit 3. Combination switch 4. Body ECU	DI-1035 DI-1019 BE-23 –

ILLUMINATION LIGHT SYSTEM:

Symptom	Suspect Area	See page
All switch illumination light does not light up.	1. Power source circuit 2. Light control rheostat 3. Body ECU	DI-996 BE-41 –
Each switch illumination light does not light up.	1. Illumination light circuit 2. Body ECU	DI-1042 –
Brightness does not change even when rheostat turned. (All)	1. Light control rheostat 2. Body ECU	BE-41 –
Door courtesy light does not light up.	1. Door courtesy switch circuit 2. Body ECU	DI-1008 –

DRIVER SEAT BELT SYSTEM:

Symptom	Suspect Area	See page
Driver seat belt warning does not light up.	1. Driver buckle switch circuit 2. Body ECU	DI-1027 –

WIRELESS DOOR LOCK CONTROL SYSTEM:

Symptom	Suspect Area	See page
Wireless door lock does not operate.	1. Wireless door lock control circuit 2. Body ECU	DI-1038 –

DOUBLE LOCKING SYSTEM

Symptom	Suspect Area	See page
Double locking system does not operate.	1. Double lock switch circuit 2. Double lock motor circuit 3. Double locking system 4. Body ECU	DI-1013 DI-1016 BE-1 DI-979

OTHERS:

Symptom	Suspect Area	See page
Key unlock warning system does not operate.	1. Key unlock warning switch circuit 2. Body ECU	DI-1006 –

DIAGNOSTICS – BODY CONTROL SYSTEM

Parking brake indicator does not light up.	1. Parking brake switch circuit 2. Combination meter 3. Body ECU	DI-1025 BE-33 –
Open door warning light does not light up.	1. Open door warning light circuit 2. Door courtesy switch 3. Body ECU	DI-1040 DI-1008 –