

DTC	B1276	Mirror ECU communication stop
------------	--------------	--------------------------------------

CIRCUIT INSPECTION

This DTC is output when communication stops between the Mirror control ECU and the Body ECU.

DTC No.	DTC Detecting Condition	Trouble Area
B1276	No communication from mirror control ECU for more than 10 seconds.	• Mirror control ECU • Wire harness

WIRING DIAGRAM

See page DI-1118.

INSPECTION PROCEDURE

1	Check mirror control ECU.
----------	----------------------------------

CHECK:

Check that the mirror control system operates normally.

HINT:

With this inspection, whether or not the mirror control ECU CPU functions normally can be diagnosed.

NG

Replace the mirror control ECU (See page IN-38).

YES

2 Check wire harness. (See page IN-38)


PREPARATION:

Pull out the ECU connectors mentioned below.

Wire harness side connector of ECU	Terminal
Mirror control ECU – Power seat ECU	MPX1 (R47-25) – MPX2 (S32-9)
Mirror control ECU – Tilt and telescopic ECU	MPX1 (R47-13) – MPX1 (T11-8)

CHECK:

Check continuity of the wire harness between the connectors.



OK:

There is a continuity between the connectors.

HINT:

If there is OPEN in any wire harness, please repair it.

NG

Repair or replace wire harness.

OK

Replace mirror control ECU (See page IN-38).