

CIRCUIT INSPECTION

1. Black screen (Nothing displayed)

INSPECTION PROCEDURE

1 Check the ECU-B1, ECU-IG1 and ACC fuse.

NG

Replace the fuse.

OK

2 Check multi-display.

PREPARATION:

Disconnect the multi- display connector.

CHECK:

Check voltage terminals +B1.

OK:

+B: 10 – 14 V

CHECK:

Check voltage terminal ACC when turn ignition switch ACC or ON position.

OK:

ACC: 10 – 14 V

CHECK:

Check voltage terminal IG when turn ignition switch ON position.

OK:

IG: 10 – 14 V

CHECK:

Check continuity terminal GND1.

OK:

GND1: Continuity

NG

Replace or repair wire harness or connector.

OK

Replace the multi-display.