

7. Navigation screen not stabilized (Synchronous error).

INSPECTION PROCEDURE

1	Check the navigation ECU.
---	---------------------------

CHECK:

Check terminals +B.

OK:**+B: 10 – 14 V****CHECK:**

Check terminal ACC when turn ignition switch ACC or ON position.

OK:**ACC: 10 – 14 V****CHECK:**

Check terminal SYNC, VR or VG.

OK:**SYNC, VR, VG: See "Navigation ECU" of "TERMINAL OF ECU"****NG****Repair or replace the wire harness when all terminals are faulty. Replace the navigation ECU when the SYNC terminal is faulty.****OK****Replace the multi-display.**