

13. MAP screen display does not appear. (Disc Caution screen does not change)

INSPECTION PROCEDURE

1 Take appropriate measures according to the caution screen.

OK

Normal.

NG

2 Check map DISC.

NG

Replace the disc.

OK

Replace the navigation ECU.

CAUTION SCREEN

CAUTION MESSAGE	CAUSE	CORRECTIVE ACTION
The DVD cover is open. Close it and perform operation again.	The cover of the map disk slot is open.	Close the cover,
No DVD. Please insert map DVD.	No map disk is inserted.	Insert a proper map disc.
Unable to read DVD correctly. Check if the DVD is damage or dirty.	Data cannot be read because the map disc is dirty or scratched.	Wipe off dirt on the both disc surface with soft cloth.
Unable to read data. Check if map DVD is correct.	Something other than map disc is inserted.	Insert a correct map disc.
Unable to read data. Consult your dealer.	The player cannot read data from the map disc temporarily.	Turn the ignition switch OFF and ON.*1

*1: If the same caution screen appears again after turning the ignition switch ON, replace the navigation ECU.