

16. Touch switch does not function. (A/C control screen only)

INSPECTION PROCEDURE

1 Display check mode (Touch switch, Touch point screen).

NG

Replace the multi-display.

OK

2 Check "AVC-LAN communication circuit" ([See page DI-1215](#)).

NG

Replace or repair AVC-LAN circuit.

OK

3 Check "Gateway ECU (AVC-LAN adopter) circuit" ([See page DI-1221](#)).

NG

Repair or replace wire harness and connector

OK

Check and replace A/C amplifier (Center ECU).