

22. No voice navigation.

INSPECTION PROCEDURE

- | | |
|---|---|
| 1 | Set the volume to the max in the menu screen. |
|---|---|

OK

Normal. (Voice navigation is not available. No destination is set, or the vehicle is running off the route.)

NG

- | | |
|---|---|
| 2 | Check wire harness (navigation ECU and driver side door speaker). |
|---|---|

PREPARATION:

Disconnect the navigation ECU connector and driver side door speaker connector.

CHECK:

- (a) Check continuity between terminal AUO+ of navigation ECU connector and terminal 1 of driver side door speaker.
- (b) Check continuity between terminal AUO- of navigation ECU connector and terminal 2 of driver side door speaker.

OK:

Continuity

NG

Replace or repair wire harness.

OK

- | | |
|---|---|
| 3 | Check the sound (Check if the radio sound can be heard from the driver side door speaker.). |
|---|---|

OK

Replace the navigation ECU.

NG

Replace the speaker.