

REPLACEMENT

REPLACEMENT REQUIREMENTS

In the following cases, replace the curtain shield airbag sensor assembly.

- If the curtain shield airbag sensor assembly has been deployed in a collision.
- If the curtain shield airbag sensor assembly has been found to be faulty in troubleshooting.
- If the curtain shield airbag sensor assembly has been dropped.

CAUTION:

For removal and installation of the curtain shield airbag sensor assembly, [see page RS-97](#) and [RS-100](#). Be sure to follow the correct procedure.