






REPLACEMENT

1. REPLACE FRONT BEARING


- (a) Remove the 4 screws, bearing retainer and bearing.



- (b) Using SST and a hammer, tap out the bearing.
SST 09950-60010 (09951-00250), 09950-70010 (09951-07100)



- (c) Using SST and a press, press in a new bearing.
SST 09950-60010 (09951-00470), 09950-70010 (09951-07100)
- (d) Install the bearing retainer with the 4 screws.
Torque: 2.6 N·m (27 kgf·cm, 23 in·lbf)




2. REPLACE REAR BEARING


- (a) Using SST, remove the bearing cover (outside) and bearing.
SST 09820-00021

NOTICE:

Be careful not to damage the fan.



- (b) Using SST and a press, press in a new bearing.
SST 09820-00031



- (c) Using SST, push in the bearing cover (outside).
SST 09285-76010