

DTC	B1232	Jam protection pulse switch circuit on driver door
------------	--------------	---

CIRCUIT DESCRIPTION

This DTC is output when failure of the jam protection pulse switch circuit is detected.

The jam protection pulse switch is built in the power window motor.


The pulse switch outputs ON/OFF pulse when the motor rotates.

DTC No.	DTC Detecting Condition	Trouble Area
B1232	No change in pulse switch more than 2.0 seconds even if opening glass down when limit switch is OFF (window glass is fully closed).	- Jam protection pulse switch - Wire harness

HINT:

When the power window is operated UP or DOWN to detect the 30 cycle or more of the ON-OFF pulse, this DTC is cleared.

WIRING DIAGRAM



INSPECTION PROCEDURE

HINT:

In case of not using the hand-held tester, start from step 3.

1	Whether or not this DTC is cleared when the power window is lowered from fully close condition to half opened condition.
---	--

Yes

It is suspected that the DTC was detected by ECU with any failure in the past.

No

2	Check jam protection pulse switch (See page BE-79).
---	--

NG

Replace power window motor.

OK

3	Check wire harness and connector between power window motor and power window switch (See page IN-36).
---	--

NG

Repair or replace wire harness or connector.

OK

Replace Power window master switch.