

REPLACEMENT

REPLACEMENT REQUIREMENTS

In the following cases, replace the seat position sensor assembly.

- If the seat position sensor assembly has been found to be faulty in troubleshooting.
- If the seat position sensor assembly has been dropped.

CAUTION:

For removal and installation of the seat position sensor assembly, see page [RS-91](#) and [RS-94](#). Be sure to follow the correct procedure.