


Tc and CG Terminal Circuit

CIRCUIT DESCRIPTION

Connecting terminals Tc and CG of the DLC3 causes the VGRS ECU to display the DTC by blinking the VGRS warning light.


WIRING DIAGRAM



F17306

INSPECTION PROCEDURE

- | | |
|----------|---|
| 1 | Check voltage between terminals Tc and CG of DLC3. |
|----------|---|

**CHECK:**

Turn the ignition switch ON and measure the voltage between terminals Tc and CG of the DLC3.

OK:

Voltage: 10 to 14 V

OK

If VGRS warning light does not blink even after Tc and CG are connected, check VGRS warning light circuit.

NG

- | | |
|----------|--|
| 2 | Check for an open or short circuit in harness and connector between VGRS ECU and DLC3 (Tc), and DLC3 (CG) and body ground (See page IN-38). |
|----------|--|

NG

Repair or replace harness or connector.

OK

Replace VGRS ECU.