

3. No navigation screen displayed when "MAP", "Menu", or "DEST" switch pressed. (Screen cannot be switched.)

INSPECTION PROCEDURE

1 Service check mode (Check the navigation ECU)

NG

Troubleshoot for each diagnosis.

OK

Replace multi-display.

Ncon

2 Check the navigation ECU power source circuit ([see page DI-256](#)).

NG

Replace or repair wire harness or connector.

OK

3 Check multi-display power source circuit ([see page DI-259](#)).

NG

Replace or repair wire harness or connector.

OK

4 Check the display signal circuit ([see page DI-270](#)).

NG

Replace or repair wire harness or connector.

OK

Replace multi display.