

15. Touch switch does not function. (Navigation screen only)

INSPECTION PROCEDURE

1 Display check mode (Touch switch check screen)

NG

Replace the multi-display.

OK

2 Check "AVC-LAN communication circuit". ([See page DI-275](#))

NG

Replace or repair AVC-LAN circuit.

OK

Replace the navigation ECU.