

23. Vehicle position rotates without control. (Map rotates without control)

INSPECTION PROCEDURE

- | | |
|---|---|
| 1 | Recheck. (While not rotating the vehicle, turn the ignition switch ON from OFF again.) |
|---|---|

OK

Normal (While the vehicle was turning, the ignition switch was turned ON.)

NG

- | | |
|---|---|
| 2 | System check mode (Is "58-10" displayed in the unit check mode of the navigation ECU?) |
|---|---|

Yes

Replace the navigation ECU.

No

- | | |
|---|---|
| 3 | System check mode (Is "58-43" displayed in the unit check mode of the navigation ECU?) |
|---|---|

Yes

Replace and repair SPD terminal wire harness.

No

- | | |
|---|--|
| 4 | Navigation check mode (vehicle signal check mode: SPD and gyro) |
|---|--|

OK

Replace the navigation ECU.

NG

Replace or repair wire harness.