

Power source circuit

CIRCUIT DESCRIPTION

This circuit supplies power to operate the Body ECU.

WIRING DIAGRAM



INSPECTION PROCEDURE

1	Check ECU–B2, DOOR fuse.
----------	---------------------------------

CHECK:

Check continuity of ECU–B2, DOOR fuse.

OK:

Continuity

NG

Replace faulty fuse.

OK

2	Check voltage between terminals BDR1, BECU and GND1, 2 of Body ECU connector.
----------	--

PREPARATION:

- (a) Turn the ignition switch OFF.
- (b) Disconnect the Body ECU connector.

CHECK:

Measure the voltage between terminals BDR1, BECU and GND1, 2.

OK:

Voltage: 10 – 14V

OK

Proceed to next circuit inspection shown on problem symptoms table (See page [DI-1051](#)).

NG

3	Check wire harness and connector between Body ECU and body ground (See page IN-36).
----------	--

NG

Repair or replace wire harness or connector.

OK

Proceed to next circuit inspection shown on problem symptoms table (See page [DI-1051](#)).