


DTC	P0500	Vehicle Speed Sensor "A"
------------	--------------	---------------------------------

DTC	P0503	Vehicle Speed Sensor "A" Intermittent/Erratic/High
------------	--------------	---

CIRCUIT DESCRIPTION

The No.1 vehicle speed sensor outputs a 4-pulse signal for every revolution of the rotor shaft, which is rotated by the transmission output shaft via the driven gear. After this signal is converted into a more precise rectangular waveform by the waveform shaping circuit inside the combination meter, it is then transmitted to the ECM. The ECM determines the vehicle speed based on the frequency of these pulse signals.



DTC No.	Proceed to	DTC Detection Condition	Trouble Area
P0500	Step 1	No vehicle speed sensor signal to ECM under following conditions (a) and (b): (1 trip detection logic) (a) Park/neutral position switch is OFF (b) Vehicle is being driven	• Combination meter • Open or short in vehicle speed sensor circuit • Vehicle speed sensor • ECM
P0503	DI-3	Intermittent problem in the vehicle speed sensor circuit	

MONITOR DESCRIPTION

The ECM assumes that the vehicle is driven when the park/neutral position switch is OFF and it has been over 4 sec. since the actual vehicle speed was 9 km/h (6 mph) or more.

If there is no signal from the vehicle speed sensor with these conditions satisfied, the ECM concludes that there is a fault in the vehicle speed sensor. The ECM will turn on the MIL and a DTC is set.

MONITOR STRATEGY

Related DTCs	P0500	Vehicle speed sensor "A" pulse input error
Required sensors/components	Main sensors	Vehicle speed sensor
	Related sensors	Park/Neutral position switch, Engine coolant temperature sensor, Combination meter
Frequency of operation	Continuous	
Duration	500 output X 4 times	
MIL operation	Immediate	
Sequence of operation	None	


TYPICAL ENABLING CONDITIONS

Item	Specification	
	Minimum	Maximum
The monitor will run whenever the following DTCs are not present	See "List of disable a monitor" (on page DI-3)	
Vehicle speed is 9 km/h (6 mph) or more	4 sec.	–
Park/neutral position switch	OFF	
Transfer neutral switch	Not "N" position	

TYPICAL MALFUNCTION THRESHOLDS

Detection Criteria	Threshold
Sensor signal	No pulse input

WIRING DIAGRAM



INSPECTION PROCEDURE

HINT:

Read freeze frame data using the hand-held tester or the OBD II scan tool. Freeze frame data records the engine conditions when a malfunction is detected. When troubleshooting, freeze frame data can help determine if the vehicle was running or stopped, if the engine was warmed up or not, if the air-fuel ratio was lean or rich, as well as other data from the time when a malfunction occurred.

1	Check operation of speedometer.
----------	--

CHECK:

Drive the vehicle and check if the operation of the speedometer in the combination meter is normal.

HINT:



The vehicle speed is operating normally if the speedometer display is normal.

NG

Check speedometer circuit. See combination meter troubleshooting (See page [BE-2](#)).

OK

2 Check voltage between terminal SPD and E1 of ECM connector.



PREPARATION:

- (a) Shift the shift lever to neutral.
- (b) Jack up the rear wheel on one side.
- (c) Turn the ignition switch ON.

CHECK:

Measure the voltage between the specified terminal of the E7 and E8 ECM connector when the wheel is turned slowly.

OK:

Tester Connection	Specified Condition
SPD (E8-17) - E1 (E7-1)	Generated intermittently

HINT:

The output voltage should fluctuate up and down similarly to the diagram on the left when the wheel is turned slowly.

NG

Check and repair harness and connector between combination meter and ECM.

OK

Replace ECM (See page SF-60).