

7. Navigation screen not stabilized (Synchronous error).

INSPECTION PROCEDURE

- | | |
|---|--|
| 1 | Check the navigation ECU power source circuit (see page DI-1244). |
|---|--|

NG

Replace or repair wire harness or connector.

OK

- | | |
|---|---|
| 2 | Check the display signal circuit (see page DI-1258). |
|---|---|

NG

Replace or repair wire harness or connector.

OK

Replace the multi-display.