




Service Hints

A45 (A), A47 (C) A/C Control Assembly

(A) 6–Ground : Approx. 12 volts with ignition SW at ON or ST position
(C) 12, (C) 14, (C) 15, (C) 17, (C) 18–Ground : Always continuity

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A45	A	I18	70	R32	73
A47	C	J11	71	R33	73
F16	68	J23	72		

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	24	Engine Room No.2 Wire and Engine Room J/B (Engine Compartment Left)
2A	28	Engine Room No.2 Wire and Cowl Side J/B LH (Left Kick Panel)
2B		
2C		
2D		
2E	28	Dash Wire and Cowl Side J/B LH (Left Kick Panel)
2G	28	Front Door LH Wire and Cowl Side J/B LH (Left Kick Panel)
2I		
2J		
3I	40	Front Door RH Wire and Cowl Side J/B RH (Right Kick Panel)
4C	52	Dash Wire and J/B No.4 (Instrument Panel Center)
4F		
5A	56	Dash Wire and J/B No.5 (Behind the Combination Meter)
5D	56	Engine Room No.2 Wire and J/B No.5 (Behind the Combination Meter)

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IV4	82	Dash Wire and Floor No.2 Wire (Right Kick Panel)
IY2	82	Front Door RH Wire and Dash Wire (Right Kick Panel)

▽ : Ground Points

Code	See Page	Ground Points Location
IF	78	Set Bolt of Cowl Side J/B LH
II	78	Set Bolt of Cowl Side J/B RH
BK	86	Front Side Under the Front Passenger's Seat