





INSPECTION

1. INSPECT BLOWER MOTOR OPERATION


Connect the battery positive (+) lead to terminal 1 and battery negative (-) lead to terminal 2, then check that the motor rotates smoothly.

If the motor rotates smoothly, check the wire harness. Otherwise, replace the blower motor.




2. INSPECT THERMISTOR RESISTANCE

- Place the thermistor in cold water.
- Measure resistance of the thermistor as the water temperature increases.



- Compare the readings with the chart.
- If the values meet the specifications, check the wire harness. Otherwise, replace the thermistor.



3. INSPECT MAGNETIC VALVE OPERATION

Check the air passage through the valve, with and without the battery positive voltage applied, between terminals as shown in the chart.

Condition	Air passage
Apply B+ between terminals	Free passage
Not apply B+ between terminals	No passage

Otherwise replace the magnetic valve with the expansion valve. If operation is as specified, check the wire harness.

4. INSPECT EVAPORATOR

- Check the evaporator fins for blockage. If the fins are clogged, remove them with compressed air.

NOTICE:

Never use water to clean the evaporator.

- Check the fitting for cracks or scratches. If necessary, repair or replace.