

DTC	P0724	Brake Switch "B" Circuit High
------------	--------------	--------------------------------------

CIRCUIT DESCRIPTION

The purpose of this circuit is to prevent the engine from stalling, while driving in lock-up condition, when brakes are suddenly applied.

When the brake pedal is operated, this switch sends a signal to ECM. Then the ECM cancels operation of the lock-up clutch while braking is in progress.

DTC No.	DTC Detection Condition	Trouble Area
P0724	Stop light switch always turn on even vehicle is driver Go and Stop 5 times. (2-trip detection logic)	• Short in stop light switch signal circuit • Stop light switch • ECM

MONITOR DESCRIPTION

When the stop light switch remains ON during "stop and go" driving, the ECM interprets this as a fault in the stop light switch and the MIL comes on and the ECM stores the DTC. The vehicle must stop and go (3 km/h (2 mph) to 30 km/h (19 mph)) 5 times for two driving cycles in order to detect malfunction.

MONITOR STRATEGY

Related DTCs	P0724	Stop light switch/Range check/Rationality
Required sensors/Components	Main	Stop light switch
	Sub	Vehicle speed sensor
Frequency of operation	Continuous	
Duration	GO and STOP 5 times	
MIL operation	2 driving cycles	
Sequence of operation	None	

TYPICAL ENABLING CONDITIONS

Item	Specification	
	Minimum	Maximum
The monitor will run whenever the following DTCs are not present.	See page DI-369	
The stop light switch remains on during GO and STOP 5 times.		
GO and STOP are defined as follows;		
GO (Vehicle speed is 30 km/h (18.63 mph) or more)	Once	
STOP (Vehicle speed less than 3 km/h (1.86 mph))	Once	
Starter	OFF	
Battery voltage	8 V or more	–
Ignition switch	ON	

TYPICAL MALFUNCTION THRESHOLDS

Detection criteria	Threshold
Brake switch	ON stuck

WIRING DIAGRAM

See page [DI-284](#).

INSPECTION PROCEDURE

