

Security indicator circuit


CIRCUIT DESCRIPTION

When the theft deterrent system is preparing to be set, this circuit lights up the indicator.

When the system is set, the indicator blinks.

It also indicates the condition of the immobiliser system according to the request from the Transponder Key ECU.

WIRING DIAGRAM



INSPECTION PROCEDURE

HINT:

In case of using the hand-held tester, start the inspection from step 1 and in case of not using the hand-held tester, start from step 2.

1	Check security indicator using hand-held tester.
---	---

PREPARATION:

Connect the hand-held tester to the DLC 3.

CHECK:


Check that the theft deterrent in the indicator lights in ACTIVE TEST (See page [DI-962](#)).

OK

Proceed to next circuit inspection shown in problem symptoms table (See page [DI-970](#)).

NG

2	Check security indicator.
---	----------------------------------



CHECK:

Connect the positive lead from the battery to terminal 7 (14) and negative lead to terminal 6 (8), and check that the warning light lights up.

(): w/o Navigation system

OK:

Indicator light lights up.

NG


Replace multi-display.

OK

3	Check wire harness and connector between theft deterrent ECU and indicator, indicator and body ground (See page IN-36).
---	--

NG

Repair or replace wire harness or connector.

OK

Proceed to next circuit inspection shown in problem symptoms table (See page [DI-970](#)).