


Wire Harness Side



G-7-1

3. INSPECT TRANSMISSION CONTROL ECU


Disconnect the ECU connector and inspect the connector on the wire harness side as shown in the chart.

Check for	Tester connection	Condition	Specified value
Voltage	1 – Body ground	Turn ignition switch ON	Battery voltage
		Turn ignition switch OFF	No voltage
Continuity	2 – 5	—	3.38 kΩ at 25°C (77°F)
Voltage	3 – Body ground	Turn ignition switch ON	Battery voltage
		Turn ignition switch OFF	No voltage
Voltage	6 – Body ground	Turn ignition switch ON	No voltage
		Engine running	Battery voltage
Continuity	7 – Body ground	—	Continuity

If circuit is as specified, replace the ECU.

Neutral Start Switch**INSPECT NEUTRAL START SWITCH**

Using an ohmmeter, check the continuity of the terminals for each switch position shown in the table below.



IC-3-2 IH-3-2

Shift position \ Terminal	C	RL	N	B	PL
P range	○		○	○	○
R range	○	○			
N range			○	○	

If continuity between the terminals is not as specified, replace the switch.