


STEERING LINKAGE COMPONENTS



kg-cm (ft-lb, N·m) : Specified torque

◆ Non-reusable part


REMOVAL OF STEERING LINKAGE

1. REMOVE WHEEL

2. DISCONNECT RELAY ROD FROM PITMAN ARM

- (a) Remove the cotter pin and nut.
- (b) Using SST, disconnect the relay rod from the pitman arm.


SST 09628-62011



3. DISCONNECT TIE ROD FROM KNUCKLE ARM

- (a) Remove the cotter pin and nut.
- (b) Using SST, disconnect the tie rod from the knuckle arm.


SST 09611-22012



4. DISCONNECT STEERING DAMPER FROM DAMPER BRACKET

- (a) Remove the nut.
- (b) Using SST, disconnect the steering damper from the damper bracket.


SST 09628-12022



5. DISCONNECT STEERING DAMPER FROM RELAY ROD

- (a) Remove the nut.
- (b) Using SST, disconnect the steering damper from the relay rod.


SST 09611-22012




6. DISCONNECT RELAY ROD FROM TIE ROD

- (a) Remove the cotter pin and nut.
- (b) Using SST, disconnect the relay rod from the tie rod.

SST 09628-62011





A4438

INSPECTION OF STEERING LINKAGE

1. INSPECT BALL JOINT FOR ROTATION CONDITION


- Clamp the ball joint in vise.
- As shown in the figure, flip the ball joint stud back and forth 5 times before installing the nut.
- Using a torque gauge, turn the nut continuously one turn each 2 – 4 seconds and take the torque reading on the fifth turn.

Torque (turning): 10 – 30 kg-cm

(8.7 – 26.0 in.-lb, 1.0 – 2.9 N-m)

2. IF NECESSARY, REPLACE TIE ROD END


- Loosen the tie rod end clamp and remove the tie rod end.



D3148

- Turn the tie rod ends in equal amounts into the tie rod tube. Tie rods should be approx. 1,267 mm (49.88 in.).


- Temporarily tighten the tie rod end clamp.



D3156


3. IF NECESSARY, REPLACE RELAY ROD END

- Loosen the relay rod end clamp and remove the relay rod end.
- Remove the cotter pin.






D3149

- Using a screwdriver, remove the plug, two ball stud seats, link joint knob, spring and spring seat.



D3151




- (d) Apply molybdenum disulphide lithium base grease to the joint parts.
- (e) Install the spring seat, spring, link joint knob and two ball stud seats.
- (f) Tighten the plug completely.
- (g) Loosen the plug with 1 - 1 1/3 turns and install a new cotter pin.

- (h) Turn the relay rod ends in equal amounts into the relay rod tube.
Relay rod should be approx. 1,001 mm (39.41 in.).

- (i) Torque the clamp bolts.

Torque: 450 kg-cm (33 ft-lb, 44 N-m)




INSTALLATION OF STEERING LINKAGE

1. CONNECT RELAY ROD TO TIE ROD

(a) Torque the nut.

Torque: 925 kg-cm (67 ft-lb, 91 N-m)


(b) Install a new cotter pin.



2. CONNECT STEERING DAMPER TO RELAY ROD

Torque a new nut.


Torque: 750 kg-cm (54 ft-lb, 74 N-m)



3. CONNECT STEERING DAMPER TO DAMPER BRACKET

Torque a new nut.

Torque: 750 kg-cm (54 ft-lb, 74 N-m)




4. CONNECT TIE ROD TO KNUCKLE ARM

(a) Torque the nut.

Torque: 925 kg-cm (67 ft-lb, 91 N-m)

(b) Install a new cotter pin.



5. CONNECT RELAY ROD TO PITMAN ARM

(a) Torque the nut.

Torque: 925 kg-cm (67 ft-lb, 91 N-m)

(b) Install a new cotter pin.

6. APPLY MOLYBDENUM DISULPHIDE LITHIUM BASE GREASE TO BOTH NIPPLES

7. INSTALL WHEEL

8. ADJUST TOE-IN

(See page [SA-5](#))