

ABBREVIATIONS USED IN THIS MANUAL

IN024-01

AAP	Auxiliary Acceleration Pump
ASV	Air Switching Valve
A/T	Automatic Transmission
BTDC	Before Top Dead Center
CB	CHock Breaker
DOHC	Double Over Head Cam
DP	Dash Pot
ECU	Electronic Control Unit
ESA	Electronic Spark Advance
EX	Exhaust (Manifold, Valve)
Ex.	Except
FICB	Fast Idle Cam Breaker
FIPG	Formed in Place Gasket
FL	Fusible Link
IC	Integrated Circuit
IG	Ignition
IN	Intake (Manifold, Valve)
J/B	Junction Block
LH	Left — Hand
Max.	Maximum
Min.	Minimum
MP	Multipurpose
M/T	Manual Transmission
O/S	Oversize
OVCV	Outer Vent Control Valve
PCV	Positive Crankcase Ventilation
RH	Right — Hand
SSM	Special Service Materials
SST	Special Service Tools
STD	Standard
TCCS	Toyota Computer Controlled System
TDC	Top Dead Center
TEMP.	Temperature
TP	Throttle Positioner
U/S	Undersize
VCV	Vacuum Control Valve
VSV	Vacuum Switching Valve
w/	With
w/o	Without