



## DISTRIBUTOR COMPONENTS



## REMOVAL OF DISTRIBUTOR


1. REMOVE AIR CLEANER HOSE
2. DISCONNECT DISTRIBUTOR CONNECTOR
3. DISCONNECT VENTILATION HOSES
4. DISCONNECT HIGH-TENSION CORDS FROM SPARK PLUGS AND IGNITION COIL



### 5. REMOVE DISTRIBUTOR

Remove the mount bolt and pull out the distributor.

### 6. REMOVE O-RING FROM DISTRIBUTOR HOUSING




## REPLACEMENT OF DISTRIBUTOR DRIVEN GEAR


### 1. REMOVE DRIVEN GEAR

- (a) Using a grinder, grind the driven gear and straight pin.

**NOTICE:** Be careful not to damage the governor shaft.




- (b) Mount the driven gear in a vise.
- (c) Using a pin punch and hammer, tap out the straight pin.
- (d) Remove the driven gear.




### 2. INSTALL NEW DRIVEN GEAR

- (a) Slide a new driven gear onto the governor shaft.
- (b) Position the drill mark on the driven gear and rotor as shown.



- (c) Install a new straight pin.
- (d) Secure the ends of the straight pin.



## INSTALLATION OF DISTRIBUTOR


### 1. SET NO. 1 CYLINDER TO TDC/COMPRESSION

Set to TDC/compression in the following manner.

- Remove the No. 1 spark plug.
- Place your finger over the hole of the No. 1 spark plug and turn the crankshaft clockwise to TDC/compression. If pressure is felt on your finger, this is TDC/compression. If not, repeat the process.
- Install the No. 1 spark plug.


### 2. SET OIL PUMP SHAFT SLOT

Position the oil pump shaft slot in the direction shown in the illustration.




### 3. INSTALL NEW O-RING

- Install a new O-ring to the housing.
- Apply a light coat of engine oil on the O-ring.




### 4. INSTALL DISTRIBUTOR

- Insert the distributor, aligning the center of the flange with that of the bolt hole on the cylinder head with drilled mark facing upward.



- When fully installed, the distributor should point as shown in the illustration.
- Lightly tighten the hold-down bolt.



## 5. INSTALL DISTRIBUTOR CAP WITH HIGH-TENSION CORDS

## 6. CONNECT HIGH-TENSION CORDS TO SPARK PLUGS

Firing order: 1 – 5 – 3 – 6 – 2 – 4

## 7. CONNECT VENTILATION HOSES

## 8. CONNECT DISTRIBUTOR CONNECTOR

## 9. INSTALL AIR CLEANER HOSE

## 10. WARM UP ENGINE

Allow the engine to reach normal operating temperature.

## 11. CONNECT TACHOMETER AND TIMING LIGHT TO ENGINE

Connect the tachometer test probe to terminal IG(–) of the check connector.

### NOTICE:

- **NEVER** allow the tachometer terminals to touch ground as it could result in damage to the igniter and/or ignition coil.
- As some tachometers are not compatible with this ignition system, we recommend that you confirm the compatibility of your unit before using.

## 12. ADJUST IGNITION TIMING

- (a) Using SST, connect terminals TE1 and E1 of the check connector.

SST 09843-18020

- (b) Check the idle speed.

**Idle speed: 650 rpm**




- (c) Using a timing light, slowly turn the distributor until the timing mark on the drive plate is aligned with the 7° mark.

**Ignition timing: 7° BTDC @ idle**

- (d) Tighten the distributor bolt and recheck the ignition timing.

**Torque: 17 N·m (175 kgf·cm, 13 ft·lbf)**

- (e) Disconnect the check connector.



## 13. FURTHER CHECK IGNITION TIMING

**Ignition timing: Approx. 12° BTDC @ idle**

## 14. DISCONNECT TACHOMETER AND TIMING LIGHT FROM ENGINE