




HEATER RADIATOR HEATER RADIATOR REMOVAL

ACOM2-01

1. REMOVE HEATER UNIT
(See page [AC-33](#))
2. REMOVE HEATER RADIATOR
 - (a) Remove the screws and plates.
 - (b) Pull the heater radiator out.

HEATER RADIATOR INSPECTION

INSPECT FINS FOR BLOCKAGE

If the fins are clogged, clean them with compressed air.

HEATER RADIATOR INSTALLATION

1. INSTALL HEATER RADIATOR
 - (a) Insert the heater radiator to the heater unit.
 - (b) Install the plates with screws.
2. INSTALL HEATER UNIT
(See page [AC-34](#))