


POWER WINDOW SYSTEM PARTS LOCATION



DEOJM-02



TROUBLESHOOTING

The table below will be useful for you in troubleshooting these electrical problems. The most likely causes of the malfunction are shown in the order of their probability. Inspect each part in the order shown, and replace the part when it is found to be faulty.

Trouble	Parts name	(See page)
Power window does not operate at all.	1. GAUGE Fuse 2. POWER Fuse 3. Power Main Relay 4. Wire Harness	(BE-4) (BE-4) (BE-69)
"One Touch Power Window System" does not operate.	1. Power Window Master Switch	(BE-63)
Only one window does not operate.	1. Power Window Switch 2. Power Window Motor 3. Wire Harness	(BE-66) (BE-67)



BE2594

S-14-2B

Z06846

POWER WINDOW MASTER SWITCH INSPECTION

BEQJP-02

INSPECT POWER WINDOW MASTER SWITCH

Front Driver's Switch (Window unlock)/ Continuity

Switch position	Tester connection to terminal number	Specified value
UP	1 or 2 – 13 6 – 7 or 8	Continuity
OFF	1 or 2 – 6 – 13	Continuity
DOWN	1 or 2 – 6 7 or 8 – 13	Continuity

Front Driver's Switch (Window lock)/ Continuity

Switch position	Tester connection to terminal number	Specified value
UP	1 or 2 – 13 6 – 7 or 8	Continuity
OFF	1 or 2 – 6 – 13	Continuity
DOWN	1 or 2 – 6 7 or 8 – 13	Continuity

Front Passenger's Switch (Window unlock)/ Continuity

Switch position	Tester connection to terminal number	Specified value
UP	1 or 2-5 7or8 - 12	Continuity
OFF	1or2-5-12	Continuity
DOWN	lor2-12 5 - 7or8	Continuity

Front Passenger's Switch (Window lock)/ Continuity

Switch position	Tester connection to terminal number	Specified value
UP	7 or 8 - 12	Continuity
OFF	5- 12	Continuity
DOWN	5-7or8	Continuity

Rear Left Switch (Window unlock)/ Continuity

Switch position	Tester connection to terminal number	Specified value
UP	1 or 2 - 9 7or8 - 10	Continuity
OFF	1 or 2- 9 - 10	Continuity
DOWN	1 or 2-10 7 or 8-9	Continuity

Rear Left Switch (Window lock)/ Continuity

Switch position	Tester connection to terminal number	Specified value
UP	7 or 8 - 10	Continuity
OFF	9- 10	Continuity
DOWN	7 or 8-9	Continuity

Rear Right Switch (Window unlock)/ Continuity

Switch position	Tester connection to terminal number	Specified value
UP	1 or 2 - 14 7or8 - 11	Continuity
OFF	1 or 2-11 -14	Continuity
DOWN	1 or 2- 11 7 or 8 - 14	Continuity





Rear Right Switch (Window lock)/ Continuity

Switch position	Tester connection to terminal number	Specified value
UP	7 or 8 - 11	Continuity
OFF	11 - 14	Continuity
DOWN	7 or 8 - 14	Continuity


If continuity is not as specified, replace the master switch.

Illumination

- Set the window lock switch to the unlock position.
- Connect the positive (+) lead from the battery to terminal 7 and the negative (-) lead to terminal 1, check that all the illuminations light up.
- Set the window lock switch to the lock position, check that all the passenger's power window switch illuminations go out.
If operation is not as specified, replace the master switch.


**ONE TOUCH POWER WINDOW SYSTEM/ CURRENT OF CIRCUIT INSPECTION USING AN AMMETER**

- Disconnect the connector from the master switch.
- Connect the positive (+) lead from the ammeter to terminal 6 on the wire harness side connector and the negative (-) lead to negative terminal of the battery.
- Connect the positive (+) lead from the battery to terminal 13 on the wire harness side connector.
- As the window goes down, check that the current flows approximately 7 amperes.
- Check that the current increases approximately 14.5 amperes or more when the window stops going down.
HINT: The circuit breaker opens some 4 - 40 seconds after the window stops going down, so that check must be made before the circuit breaker operates.
If the operation is as specified, replace the master switch.




INSPECTION USING AN AMMETER WITH A CURRENT-MEASURING PROBE

- Remove the master switch with connector connected.
- Attach a current-measuring probe to terminal 6 of the wire harness.
- Turn the ignition switch ON and set the power window switch in the down position.
- As the window goes down, check that the current flows approximately 7 amperes.



- Check that the current increases approximately 14.5 amperes or more when the window stops going down.
HINT: The circuit breaker opens some 4 – 40 seconds after the window stops going down, so that check must be made before the circuit breaker operates.
If operation is as specified, replace the master switch.




POWER WINDOW SWITCH INSPECTION

INSPECT POWER WINDOW SWITCH

Continuity

Switch position	Tester connection to terminal number	Specified value
UP	1-5 3-4	Continuity
OFF	1-2 3-4	Continuity
DOWN	1-2 4-5	Continuity

If continuity is not as specified, replace the switch.



POWER WINDOW MOTOR INSPECTION

LEFT SIDE DOOR MOTOR/MOTOR OPERATION

Front Door:

(a) Connect the positive (+) lead from the battery to terminal 3 and the negative (-) lead to terminal 1, check that the motor turns clockwise.

(b) Reverse the polarity, check that the motor turns counterclockwise.


If operation is not as specified, replace the motor.

Rear Door:

(a) Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 2, check that the motor turns counterclockwise.

(b) Reverse the polarity, check that the motor turns clockwise.

If operation is not as specified, replace the motor.




LEFT SIDE MOTOR/ CIRCUIT BREAKER OPERATION

Driver's Door:


(a) Disconnect the connector from the master switch.
(b) Connect the positive (+) lead from the battery to terminal 6 and the negative (-) lead to terminal 13 on the wire harness side connector and raise the window to full closed position.


(c) Continue to apply voltage, check that there is a circuit breaker operation noise within approximately 4 to 40 seconds.




(d) Reverse the polarity, check that the window begins to descend within approximately 60 seconds.

If operation is not as specified, replace the motor.




**Passenger's Door:**

- (a) Disconnect the connector from the power window switch.
- (b) Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 4 on the wire harness side connector, and raise the window to full closed position.
- (c) Continue to apply voltage, check that there is a circuit breaker operation noise within approximately 4 to 40 seconds.
- (d) Reverse the polarity, check that the window begins to descend within approximately 60 seconds. If operation is not as specified, replace the motor.

**RIGHT SIDE DOOR MOTOR/MOTOR OPERATION****Front Door:**

- (a) Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 3, check that the motor turns clockwise.
- (b) Reverse the polarity, check that the motor turns counterclockwise.


**Rear Door:**


- (a) Connect the positive (+) lead from the battery to terminal 2 and the negative (-) lead to terminal 1, check that the motor turns counterclockwise.
- (b) Reverse the polarity, check that the motor turns clockwise.

If operation is not as specified, replace the motor.

RIGHT SIDE DOOR MOTOR/CIRCUIT BREAKER OPERATION

See step of left side motor on page [BE-67](#).





POWER MAIN RELAY INSPECTION

DEGJX-02

INSPECT POWER MAIN RELAY

Continuity

Condition	Tester connection to terminal number	Specified value
Constant	1-3	Continuity
Apply B + between terminals 1 and 3.	2-4	Continuity

If continuity is not as specified, replace the relay.